

2010 GGG Universal Moulding Chart

BGN YR	END YR	MODEL	W/S	B/G	QTR	F/L	MTR
ACURA							
1997	2003	CL	T105B	T107B			
1986	1993	Integra	T105B				
2001	2006	MDX			T202		
2007	2010	MDX	T105B				
2007	2010	RDX	T105B				
2005	2008	RL		T202			
2002	2006	RSX	T108B				
1996	1999	SLX	T108B				
1995	2010	TL	T105B	T107B			X
2004	2010	TSX	T105B				X
AUDI							
1988	1992	80	T100B	T100B			
1988	1995	90	T100B	T100B			
1989	1994	100	T100B	T100B			
1989	1991	200	T100B	T100B			
1984	1988	5000	T100B	T100B			
2002	2008	A4		T202			X
1996	2001	A4/S4	T100B	T202			
2008	2010	A5	T202				
1995	1998	A6	T100B	T100B			
1998	2010	A6	T202	T201			
2004	2008	A8L	T201	T202			
2002	2009	Allroad Quattro	T202	T201			
2007	2010	Q7	T202				
2003	2004	RS6	T202	T201			
2000	2009	S4	T202	T203			
1995	1995	S6		T100B			
2002	2010	S6	T202	T201			
2001	2003	S8	T202				
2007	2008	S8		T201			X
2000	2000	TT Coupe	T202				
1990	1994	V8 Quattro	T100B	T100B			
BMW							
1992	2005	318/328	T107B				
2004	2005	5 Series	T105B				
2004	2010	645/650		T201			X
2002	2009	7 Series	T107B				
1999	2002	M Coupe / Roadster	T108B				
2000	2006	M3		T101B			
2006	2010	M6		T202			X
2004	2006	X3	T107B				
1999	2002	Z3 Coupe	T108B				
BUICK							
1982	2005	Century	T107BFL	T107BFL			
1985	1990	Electra	T105B	T107B			
2005	2007	LaCrosse	T101B	T101B			
2010	2010	LaCrosse	T201	T201			X
1986	1991	LeSabre	T105B	T107B		X	

[1]

2010 GGG Universal Moulding Chart

2000	2005	LeSabre		T101B			
2006	2010	Lucerne	T101	T201			X
1985	1988	Park Avenue	T105B	T107B			
1985	1996	Park Avenue		T107B			
1997	2006	Park Avenue	T108B				
1987	2004	Regal	T107BFL	T107BFL			
1979	1999	Riviera	T105BFL			X	
1991	1996	Roadmaster	T107B				
1982	1987	Skyhawk	T105B	T105B			
1986	1998	Skylark	T107B	T105B			
1985	1987	Somerset Regal	T105B	T105B			
CADILLA							
1997	2001	Catera	T108B				
1982	1988	Cimarron	T105B	T105B		X	
2003	2007	CTS	T101B	T201			
2008	2010	CTS	T202				X
1985	1993	Deville	T105B	T107B			
1994	1999	Deville	T108B				
1979	1985	Eldorado	T105B			X	
1986	1994	Eldorado	T105B	T105B			
1999	2006	Escalade	T108B				
2007	2010	Escalade/ESV/EXT	T201				
1985	1996	Fleetwood	T105B	T105B			
1985	1992	Fleetwood (RWD)	T107B				
1993	1995	Hearse	T107B				
1980	1991	Seville	T107B	T105B			
1993	1993	Sixty Special	T105B	T105B			
2004	2009	SRX	T201	T201	T202		
2010	2010	SRX	T202				X
2005	2010	STS	T201	T202			X
CHEVROL							
1985	2005	Astro	T105B				
2002	2006	Avalanche	T108B				
2007	2010	Avalanche	T201				
2004	2008	Aveo	T101B	T101RB			X
2009	2010	Aveo 5	T100B				
1987	1996	Beretta	T105B				
1997	2002	C Series Med Duty	T108B				
1982	2002	Camaro	T107B				
1987	1996	Caprice	T107B				
1982	1994	Cavalier	T105B	T105B			
1995	2005	Cavalier	T105B	T101B			X
1982	1988	Celebrity	T105B	T107B			
1981	1987	Chevette	T105B	T105B			
2004	2005	Classic	T100B	T100B			
2005	2010	Cobalt 4DR	T201	T201			X
2005	2010	Cobalt Coupe	T201	T202			X
2004	2010	Colorado	T109B		T202		
1987	1996	Corsica	T105B	T105B			
1999	2004	Corvette	T107B				
1987	1987	El Camino	T107BFL				

2010 GGG Universal Moulding Chart

2005	2009	Equinox	T107B		T202		
2010	2010	Equinox	T203				
1981	1996	G Series Van	T109B				
1987	2005	Impala	T105BFL				
2006	2010	Impala	T201	T201			X
1994	1996	Impala SS	T107B				
1990	2001	Lumina	T107B			X	
1990	1996	Lumina APV	T107B				
1997	2003	Malibu	T101RB	T100B			
2004	2010	Malibu	T201	T201	T202		X
1998	2001	Metro	T105B	T105B			
1987	2009	Monte Carlo	T105BFL			X	
2000	2005	Monte Carlo	T105BFL	T105BFL		X	
1999	2000	Pickup	T108B				
1983	1994	S10 Blazer	T105B			X	
1995	2005	S10 Blazer	T108B			X	
1982	1992	S10 Pickup	T105B			X	
1994	2003	S10 Pickup	T108B			X	
1995	1996	Series 50-65-70	T108B				
1999	2006	Silverado	T107B				
2007	2010	Silverado	T201				
2003	2006	SSR	T107B				
1993	2006	Suburban	T107B				
2007	2010	Suburban	T201				
1995	2006	Tahoe	T107B				
2007	2010	Tahoe	T201				
1998	1998	Tracker	T105B				
1999	2006	Tracker	T101B				
2002	2009	TrailBlazer / EXT	T105B				
CHRYSLER							
2005	2010	300	T101B				
2008	2008	300		T201			X
1999	2004	300	T100B				
1996	2000	Cirrus	T100B	T107B			
1993	2005	Concorde	T107B	T107B			
1985	1986	Executive	T105B				
2000	2000	Grand Voyager	T100B	T202			
1990	1993	Imperial		T105B			
1984	1986	Laser		T107B		X	
1985	1995	Lebaron	T105B	T105B			
1994	1997	LHS	T107B	T107B			
1999	2001	LHS	T100B	T107B			
1988	1997	New Yorker	T107B	T107B			
1985	1988	New Yorker (FWD)	T105B				
2004	2007	Pacifica	T101B				
1995	2000	Sebring		T108B			
2001	2006	Sebring	T100B	T107BFL			
1985	1995	Town & Country	T105B	T108B			
1996	2007	Town & Country	T100B	T202			
2000	2007	Voyager	T100B	T202			
DAEWOO							

2010 GGG Universal Moulding Chart

1998	2002	Lanos	T100B	T107B			
DODGE							
1985	1988	600	T105B				
1985	1989	Aries	T105B				
1996	2000	Avenger		T108B			
1984	1995	Caravan	T105B	T108B			
1996	2007	Caravan	T100B	T202			
2006	2010	Charger	T101B	T101B			
1985	1996	Colt	T107B	T100B			
1984	1984	Colt Vista	T107B				
1989	2000	Dakota Pickup	T108B				
1984	1993	Daytona		T107B		X	
1998	2000	Durango	T108B				
1988	1993	Dynasty		T105B			
1987	1995	Grand Caravan	T105B	T108B			
1996	2007	Grand Caravan	T100B	T202			
1993	1997	Intrepid	T107B	T107B			
1998	2005	Intrepid	T100B				
1985	1989	Lancer	T105B	T105B			
2005	2008	Magnum	T100B				
1990	1992	Monaco	T107B	T108B			
1996	2005	Neon	T107B				
2007	2010	Nitro		T107B			
1989	1994	Shadow	T107B				
1989	1995	Spirit	T105B	T105B			
1991	1996	Stealth	T107B				
1995	2000	Stratus	T100B	T105B			
1994	2003	Van	T108B				
EAGLE							
1988	1989	Medallion	T107B				
1988	1992	Premier	T107B	T108B			
1989	1996	Summit	T107B	T100B			
1990	1994	Talon	T107B	T107B			
1995	1998	Talon		T108B			
1993	1997	Vision	T108B	T107B			
FORD							
1990	1997	Aerostar	T107B	T105B		X	
1994	1997	Aspire	T107B				
1995	2000	Contour	T108B				
2000	2010	Crown Victoria	T107BFL			X	X
1992	2008	Econoline	T107BFL			X	
2007	2010	Edge	T101B				X
2001	2010	Escape	T101B				
1989	2002	Escort	T105B	T107B		X	
1997	2003	Expedition	T100B				
2008	2009	Expedition	T109B				
2010	2010	Expedition	T108B				
1997	2008	F Series/150	T100B				
2009	2010	F Series/150	T201				X
2005	2007	Five Hundred	T101B	T201			X
2000	2007	Focus	T101B				

2010 GGG Universal Moulding Chart

2008	2010	Focus	T100B				
2004	2007	Freestar	T109B				
2006	2009	Fusion	T100B				
2001	2010	Lobo	T201				
1994	2004	Mustang	T107B	T107B			
2005	2010	Mustang	T101B				X
1988	1997	Probe	T105B			X	
1986	2001	Taurus	T107B	T107BFL		X	
2000	2007	Taurus	T107B	T201			X
2008	2009	Taurus		T201			
1994	1997	Thunderbird	T108B				
2010	2010	Transit	T101B				
1995	2003	Windstar	T108B	T107B			
2001	2003	ZX2	T105B			X	
GEO							
1995	1997	Metro	T107B	T105B			
1989	1997	Prizm	T105B	T105B			
1985	1989	Spectrum	T105B				
1990	1993	Storm	T107B				
1989	1997	Tracker	T105B				
GMC							
1997	2002	C Series Med Duty	T108B				
1987	1987	Caballero	T107BFL				
2004	2010	Canyon	T109B		T202		
1998	2007	Envoy	T105B			X	
1981	1996	G Series Van	T109B				
1996	2001	Jimmy	T105B			X	
1995	2002	Pickup	T108B				
1983	1994	S15 Jimmy	T105B			X	
1982	1990	S15 Pickup	T105B			X	
1985	2005	Safari	T105B				
1995	1996	Series 50-65-70	T108B				
1999	2003	Sierra	T108B				
2004	2006	Sierra	T107B				
2007	2010	Sierra	T201				
1991	1992	Sonoma S15 Pickup	T105B			X	
1993	2005	Sonoma S15 Pickup	T108B				
1995	1999	Suburban	T108B				
1995	1996	Topkick	T108B				
1992	2006	Yukon/Denali/XL	T107B				
2007	2010	Yukon/Denali/XL	T201				
HONDA							
1994	2002	Accord		T107B			
2003	2010	Accord	T105B			X	
1980	1983	Civic			T202		
1988	1995	Civic	T108B				
1996	2000	Civic		T107B			
2001	2005	Civic	T108B	T201	T202		
2006	2010	Civic	T105B	T203			
1988	1991	Civic CRX	T108B				
1993	1997	Civic Del Sol	T108B				

2010 GGG Universal Moulding Chart

2002	2010	CR-V	T105B		T202	X	
2006	2008	Fit		T202			
1994	2002	Passport	T107B				
2000	2009	S2000	T107B				
HYUNDAI							
2003	2010	Accent	T201				
2006	2010	Azera	T201				X
2001	2006	Elantra	T105B				
1990	1994	Excel	T105B				
1991	1995	Scoupe	T105B				
1995	2005	Sonata		T101B			
2006	2010	Sonata	T201	T201			X
2001	2005	XG300 / XG350		T201			X
INFINITI							
2008	2010	EX35		T201			
2003	2008	FX35		T202			
2003	2008	FX45		T202			
1999	2002	G20	T105B				
2003	2006	G35	T107BFL				
1996	1999	I30		T108B			
2000	2001	I30	T107B	T201			
2002	2005	I35	T107B	T101B			
1993	1997	J30		T107B			
2006	2010	M35	T203	T202			
2003	2010	M45	T203	T202			
2004	2008	Q45	T202	T101B			
2004	2010	QX56	T100B				
ISUZU							
1989	2000	Amigo	T105B				
2003	2007	Ascender	T105B				
2002	2005	Axiom	T107B				
1996	2000	Hombre Pickup	T108B			X	
2007	2010	i-280/290/370			T202		
1988	1989	I-Mark	T105B				
1990	1992	Impulse	T107B				
1996	1999	Oasis	T107B				
1988	1995	Pickup	T105B				
1991	2005	Rodeo	T107B				
2001	2004	Rodeo Sport	T107B				
1991	1993	Stylus	T105B				
1992	2002	Trooper	T107B				
JAGUAR							
2000	2006	S-Type	T100B				
2004	2006	Vanden Plas	T202				
2002	2006	X Type	T201	T202			
2007	2010	XK	T202	T202			
JEEP							
1993	2004	Grand Cherokee	T107B				
2005	2007	Grand Cherokee	T101B				
2002	2002	Liberty	T108B				
1987	2006	Wrangler	T107B			X	

2010 GGG Universal Moulding Chart

KIA							
2004	2007	Amanti	T201				
2001	2006	Optima		T201			X
2001	2005	Rio	T107B	T100B			
2002	2005	Rio Cinco	T101B				X
2006	2007	Rio/5	T101B				X
1994	1997	Sephia	T107B	T100B			
1998	2001	Sephia	T100B	T100B			X
2004	2009	Spectra		T101B			X
1995	2003	Sportage		T108B			
LAND RO							
1999	2004	Discovery II		T201			
2000	2005	Freelander	T101B				
2008	2010	LR2	T201				X
LEXUS							
1992	1994	ES 300	T100B				
2002	2003	ES 300 / ES 330		T100B			X
2007	2010	ES 350	T201	T201			
1998	2000	GS 300	T100B	T100B			
2001	2005	GS 300	T101B	T100B			X
1998	2000	GS 400	T100B	T100B			
2001	2005	GS 430	T101B	T100B			X
2007	2008	GS 450	T201				
2003	2006	GX 470	T101B				
2006	2010	IS 250	T201	T201			
2001	2005	IS 300		T100B			X
2002	2005	IS 300 Sport Cross		T100B			X
2006	2010	IS 350	T201	T201			
1998	2006	LX 470	T101B	T100B			
1999	2003	RX 300	T107B	T201			
2006	2009	RX 400		T201			X
1992	2000	SC 300		T107B			
1992	2000	SC 400	T107B	T107B			
2002	2010	SC 430		T202			
LINCOLN							
2003	2006	Aviator	T107BFL			X	
1995	2002	Continental	T107B	T107B			X
2000	2006	LS	T109B	T107BFL			
2006	2008	Mark LT	T100B				
1995	1996	Mark VIII	T108B				
2009	2010	MKS	T109B	T201			
2007	2010	MKX	T109B	T203			X
2007	2010	Navigator	T109B	T203			
2003	2010	Town Car	T107BFL	T101B			X
2006	2007	Zepher	T101B				
MAZDA							
2006	2010	5	T100B				
2004	2009	3	T100B	T202			
2003	2008	6	T101B	T203	T202		
1983	1992	626	T105B				
1995	2010	B Series Pickup	T107B				X

2010 GGG Universal Moulding Chart

2007	2010	CX7 / CX9	T101B				X
1990	2005	Miata	T105BFL				
2006	2009	Miata	T100B				
1995	2002	Millenia		T100B			
1996	1998	MPV	T108B	T100B			
1992	1995	MX3	T105B				
1989	1997	MX6	T107B				
1991	1994	Navajo	T107B				
1999	2002	Protege	T101B	T100B			
2002	2004	Protege 5	T101B	T100B			
1986	1995	RX7	T105B				
2004	2008	RX8	T101B	T202			
MERCURY							
1994	1997	Cougar	T108B				
2003	2010	Grand Marquis	T107BFL			X	X
2005	2007	Mariner	T101B				
2006	2009	Milan	T101B				
2005	2007	Montego	T101B	T203			X
2004	2007	Monterey	T109B				
1995	2000	Mystique	T108B				
1986	2005	Sable	T107BFL			X	
2008	2009	Sable		T201			X
1991	1996	Tracer	T108B			X	
1997	1999	Tracer	T108B	T107B		X	
1993	2002	Villager	T108B				
MITSUBISI							
1991	1999	3000GT	T107B				
1997	2005	Diamante	T107B				
1990	1993	Eclipse	T105BFL	T107BFL			
1995	1999	Eclipse		T108B			
2000	2005	Eclipse	T105B	T201			
2006	2010	Eclipse	T100B				
2004	2010	Endeavor	T100B		T202		
1992	1996	Expo	T105B				
1994	1998	Galant	T108B	T108B			
1999	2003	Galant	T101B	T101B			
2004	2009	Galant	T100B	T201			
2002	2007	Lancer	T105BFL	T100B			
1985	1996	Mirage	T107B	T100B			
1997	2002	Mirage	T100B	T100B			
1992	2000	Montero		T201			
2000	2005	Montero Sport		T201	T202		
2003	2007	Outlander	T105BFL				
2007	2010	Outlander	T100B				
1987	1994	Precis	T105B				
NISSAN							
1984	1999	200SX	T105B	T108B			
1989	1994	240SX	T107B				
1990	1996	300ZX	T105B	T105B			
1990	1996	300ZX 2+2	T105B	T105B			
2003	2007	350Z	T105BFL			X	

2010 GGG Universal Moulding Chart

1986	1997	850 Pickup	T107B			
1993	1995	Altima	T107B	T108B		
2002	2006	Altima	T105BFL	T101B		X
2008	2010	Altima		T203		
2005	2008	Armada	T101B			
1990	1990	Axxess	T105B	T100B		
1998	2001	Frontier Pickup	T107BFL			
2005	2010	Frontier Pickup	T101B			
1985	1985	Maxima	T108B			
1989	1994	Maxima	T105B	T108B		
1995	1999	Maxima	T107B	T108B		
2004	2008	Maxima		T202		
2003	2008	Murano	T202			
1991	1993	NX	T105B			
1987	2004	Pathfinder	T107B			
2005	2010	Pathfinder Armada	T101B			
1983	1983	Pulsar NX	T105B	T105B		
1983	1990	Pulsar NX	T105B			
1993	1998	Quest	T108B	T107B		
1999	2002	Quest	T108B	T100B		
2007	2010	Quest	T100B			X
1987	1999	Sentra	T105B	T105B		
2000	2006	Sentra	T105BFL	T101B		X
1985	1992	Stanza	T107B	T107B		
2004	2007	Titan	T100B			
1987	1989	Van	T105B			
2007	2010	Versa	T100B	T203		X
2005	2010	XTerra	T101B			
2001	2008	X-Trail	T101B			
OLDSMO						
1992	1998	Achieva	T107B	T107B		
1999	2004	Alero	T107B			
1991	2001	Bravada	T105B			X
2002	2004	Bravada	T108B			
1985	1987	Calais	T105B	T105B		x
1987	1992	Custom Cruiser	T105B			
1987	1987	Cutlass	T107BFL			
1997	1999	Cutlass	T101B	T100B		
1988	1991	Cutlass Calais	T105B	T105B		
1982	1996	Cutlass Ciera	T105B	T107BFL		
1987	1997	Cutlass Supreme	T107BFL			
1986	1988	Delta 88	T105B	T107B		X
1989	1991	Eighty-Eight	T105B	T107B		
1982	1988	Firenza	T105B	T105B		X
1998	2002	Intrigue	T107B	T108B		
1985	1990	Ninety-Eight	T105B	T107B		
1990	1996	Silhouette	T107B			
1979	1992	Toronado	T105B			X
PLYMOU						
1989	1995	Acclaim	T105B	T105B		
1996	2000	Breeze	T101B	T107B		

2010 GGG Universal Moulding Chart

1985	1988	Caravelle	T105B				
1985	1996	Colt	T107B	T100B			
1985	1995	Colt Vista	T105B				
1987	1995	Grand Voyager	T105B	T108B			
1996	2000	Grand Voyager	T100B	T202			
1990	1994	Laser	T107B	T107B			
1995	2001	Neon	T108B				
1997	2001	Prowler	T107B				
1985	1989	Reliant	T105B				
1988	1994	Sundance	T107B				
1992	1992	Vista	T105B				
1984	1995	Voyager	T105B	T108B			
1996	2000	Voyager	T100B	T202			
PONTIAC							
1983	1987	1000	T107B	T105B			
1983	1983	2000	T105B	T105B			
1984	1984	2000 Sunbird	T105B	T105B			
1982	1991	6000	T105B	T107B		X	
1987	1999	Bonneville	T105B	T107B		X	
2000	2005	Bonneville		T101B			X
1984	1988	Fiero	T105B			X	
1982	2002	Firebird	T107B				
2007	2009	G5		T202			
2005	2010	G6	T201	T201			X
1985	2005	Grand Am	T105B	T107B		x	
1987	1996	Grand Prix	T107BFL	T107B			
1997	2003	Grand Prix		T108B			
2005	2008	Grand Prix		T101B			X
2004	2006	GTO	T109B	T100B			
1982	1982	J2000	T105B	T105B			
1989	1993	LeMans	T105B	T105B			
1987	1989	Safari	T105B				
2006	2009	Solstice	T203				
1985	1994	Sunbird	T105B	T105B			
1995	2005	Sunfire		T101B			X
1981	1982	T1000	T105B	T105B			
2006	2009	Torrent	T107B		T202		
1990	1996	Trans Sport	T107B				
2003	2007	Vibe	T100B				X
PORSCHE							
1999	2005	911 Carrera		T202			
2003	2007	Cayenne	T202				
SAAB							
2006	2009	9-5		T101BR			
2000	2009	9-7x	T105B				
SATURN							
2008	2008	Astra	T201				X
2007	2009	Aura	T201	T202			
2003	2008	Ion	T108B	T108B			
2001	2003	L100	T107B	T107B			
2001	2003	L200	T107B	T107B			

2010 GGG Universal Moulding Chart

2004	2006	L300	T107B	T107B			
2000	2000	LS	T107B	T107B			
2000	2000	LW	T107B	T107B			
2001	2003	LW200	T107B	T107B			
2001	2004	LW300	T107B	T107B			
2007	2007	Outlook	T203				
1997	2002	SC1 / SC2	T107B				
2007	2009	Sky	T201				
1996	2002	SL1 / SL2	T107B				
1996	1999	SW1 / SW2	T107B				
2002	2007	Vue	T108B				
SCION							
2005	2010	TC		T202			
2004	2007	XA	T101B				X
2004	2010	XB	T101B				X
SUBARU							
2006	2008	B9 Tribeca		T202			
2001	2008	Forester		T202			
1993	2001	Impreza	T108B	T108B			
2004	2008	Impreza		T203			
1989	1994	Justy	T105B				
1990	1999	Legacy	T105B				
2000	2006	Legacy		T101B			
2010	2010	Legacy	T201				
2000	2006	Outback		T101B			
2010	2010	Outback	T201				
1985	1991	XT / XT6	T105B				
SUZUKI							
2002	2006	Aerio	T101B				X
1995	2002	Esteem	T107B	T100B			
2009	2010	Equator	T101B				
2005	2008	Forenza		T202			
1999	2002	Grand Vitara	T101B				
2001	2003	Grand Vitara			T202		
2005	2008	Reno		T202			
1989	1998	Sidekick	T105B				
1995	2002	Swift	T105B	T100B			
2007	2010	SX4	T100B	T100B			
1996	1998	X-90	T108B				
2004	2006	XL-7			T202		
2007	2008	XL-7	T107B				
TOYOTA							
2003	2008	4Runner	T101B		T202		
1995	1999	Avalon	T107B	T100B			
2000	2007	Avalon	T101B	T100B			X
1992	1996	Camry		T107B			
2002	2006	Camry	T101B	T100B			X
2007	2010	Camry	T201	T202			X
1990	1999	Celica	T107B	T107B			
2000	2002	Celica	T101B				
2003	2006	Celica	T101B				

2010 GGG Universal Moulding Chart

1993	1997	Corolla	T107B	T107B			
1998	2007	Corolla		T100B			X
2000	2005	Echo		T201			
2001	2003	Highlander	T108B	T202			
2004	2006	Highlander	T101B	T202			
1998	2007	Land Cruiser	T101B	T100B			
2008	2010	Land Cruiser	T202	T201			
2000	2005	MR2	T100B				
1992	1995	Paseo	T107B	T107B			
1996	1997	Paseo	T101B	T100B			
2001	2006	Prius	T101B	T202			X
1996	2000	RAV4	T107B				
2001	2010	RAV4	T101B	T202			
2001	2006	Sequoia	T101B		T202		
1998	2003	Sienna	T107B				
2004	2010	Sienna		T201			
1981	1984	Starlet			T202		
1993	1998	Supra	T105B	T105B			
1993	1998	T100 Pickup	T107B				
2001	2004	Tacoma Pickup			T202		
1991	1994	Tercel	T105B				
1995	1998	Tercel	T101B	T100B			
2005	2009	Tundra Pickup	T101B				X
2006	2010	Yaris 2DRHB	T201				
2007	2010	Yaris 4DSD	T101B				
VOLKSW							
1995	2002	Cabrio	T201				
1992	2005	Eurovan	T100B				
1985	1996	Golf	T107B				
1997	2006	Golf	T201				X
2000	2006	Golf		T202			
2007	2007	Golf	T202				
1993	1995	Golf III	T201				
1999	2009	GTI	T201				X
1986	1989	Jetta	T107B				
1998	2010	New Beetle	T201	T202			X
1998	2001	Passat	T201				X
1998	2005	Passat	T201	T202			X
2004	2005	R32	T201	T202			X
2006	2009	Rabbit	T201				
2008	2008	Tiguan	T201				
2004	2007	Touareg	T202				
VOLVO							
1979	1990	200 Series	T109B				
2008	2010	C30	T201				X
1998	2005	C70	T107B	T100B			
2006	2010	C70	T201				
2000	2010	S40 / S60	T201	T201			X
2001	2006	S60	T107B				
1998	2000	S70	T107B				
1999	2006	S80	T107B				

2010 GGG Universal Moulding Chart

2007	2009	S80	T201	T201			X
1998	1998	S90	T107B				
2000	2004	V40	T100B	T201			
2005	2010	V50	T201				
1998	1998	V90	T107B				
2003	2004	XC70	T101B				
2005	2009	XC70	T201				X
2003	2010	XC90	T201				X

[\[1\]](#)

NOTES:

- X in the Miter column may require a miter cut and glue to create a corner moulding.
- Use of T201 - T202 - T203 may be recommended for removal and reinstallation of exposed edge parts.
- GGG Corp provides this chart as a referral guide only.