

NOTES ABOUT THE CHART:
 *X in the miter (MTR) column may require a miter cut and glue to create a corner moulding.
 •Use of T201, T202 and T203 may be recommended for removal and reinstallation of exposed edge parts.
 •GGG Corp provides this chart as a referral guide only.



2010

UNIVERSAL MOULDING APPLICATION CHART

1000's OF APPLICATIONS

Distributed By:

Moulding Tools

GTOOL500

Cut mitered corners easily.
Precise mitered & straight cuts.

GGLUE

Use GGLUE to quickly bond the moulding together. Apply sparingly to the cut edge of the moulding. Press together and hold. GGLUE is especially formulated to bond Gold Glass Mouldings fast and is available in black.

Close-up of mitered corner

GTOOL201

for use with the T-201

Original Line	T-105B	T-107B	T-108B	T-109B	T-105BFL	T-107BFL
Economy® Line	ET-105B	ET-107B	ET-108B	ET-109B	ET-105BFL	ET-107BFL
<p>These mouldings are available in Original or Economy®</p>						
<p>Other Mouldings Available</p>						

Sample Boards

Original T-BRD Economy® ET-BRD

YEAR	MODEL	W/S	B/G	QTR	MTR
1997 2003	CL	T105B	T107B		
1985 1993	Integra	T105B			
2001 2006	MDX			T202	
2007 2010	MDX	T105B			
2007 2010	RDX	T105B			
2005 2008	RL		T202		
2002 2006	RSX	T108B			
1996 1999	SLX	T108B			
1995 2010	TL	T105B	T107B		X
2004 2010	TSX	T105B			X
AUDI					
1988 1992	80	T100B	T100B		
1988 1995	90	T100B	T100B		
1989 1994	100	T100B	T100B		
1990 1991	200	T100B	T100B		
1984 1988	5000	T100B	T100B		
2002 2008	A4	T202			X
1996 2001	A4/S4	T100B	T202		
2008 2010	A5	T202			
1995 1998	A6	T100B	T100B		
1998 2010	A6	T202	T201		
2004 2008	A8L	T201	T202		
2002 2009	Allroad Quattro	T202	T201		
2007 2010	Q7	T202			
2003 2004	RS6	T202	T201		
2000 2009	S4	T202	T203		
1995 1995	S6	T202	T100B		
2002 2010	S6	T202	T201		
2007 2008	S8	T202			
2000 2000	TT Coupe	T202	T201		X
1990 1994	V8 Quattro	T100B	T100B		
BMW					
1992 2005	318i/328	T107B			
2004 2005	5 Series	T105B			
2004 2010	645i/650		T201		X
2002 2009	7 Series	T107B			
1999 2002	M Coupe / Roadster	T108B			
2000 2006	M3		T101B		
2006 2010	M6		T202		X
2004 2006	X3	T107B			
1999 2002	Z3 Coupe	T108B			
BUICK					
1982 2005	Century	T107BFL	T107BFL		
1985 1990	Electra	T105B	T107B		
2005 2007	LaCrosse	T101B	T101B		
2010 2010	LaCrosse	T201	T201		X
1986 1991	LeSabre	T105B	T107B		
2000 2005	LeSabre	T101B	T201		X
2006 2010	Lucerne	T101	T201		
1985 1988	Park Avenue	T105B	T107B		
1985 1996	Park Avenue	T108B	T107B		
1997 2006	Park Avenue	T108B	T107B		
1987 2004	Regal	T107BFL	T107BFL		
1979 1999	Riviera	T105BFL			
1991 1996	Roadmaster	T107B			
1982 1987	Skyhawk	T105B	T105B		
1986 1988	Skyhawk	T107B	T105B		
1985 1987	Somerset Regal	T105B	T105B		
CADILLAC					
1997 2001	Catera	T108B			
1982 1988	Cimarron	T105B	T105B		
2007 2010	CTS	T101B	T201		
2008 2010	CTS	T202			X
1985 1993	Deville	T105B	T107B		
1994 1999	Deville	T108B			
1979 1985	Eldorado	T105B	T105B		
1986 1984	Eldorado	T105B	T105B		
1993 2006	Escalade	T108B	T101B		
2007 2010	Escalade/ESV/EXT	T201			
1985 1996	Fleetwood	T105B	T105B		
1985 1992	Fleetwood (RWD)	T107B			
1993 1995	Hearse	T107B			
1980 1991	Seville	T107B	T105B		
1993 1993	Sixty Special	T105B	T105B		
2010 2010	SRX	T202		T202	
2005 2010	STS	T201	T202		X
CHEVROLET					
1985 2005	Astro	T105B			
2002 2006	Avalanche	T108B			
2007 2010	Avalanche	T201			
2009 2010	Aveo	T101B	T101RB		X
1987 1996	Beretta	T105B			
1997 2002	C Series Med Duty	T108B			
1982 2002	Camaro	T107B			
1987 1996	Caprice	T107B			
1982 1994	Cavalier	T105B	T105B		
1985 2005	Cavalier	T105B	T101B		X
1982 1988	Celebrity	T105B	T107B		
1981 1987	Chevette	T105B	T105B		
2004 2005	Classic	T100B	T100B		
2005 2010	Cobalt 4DR	T201	T201		X
2005 2010	Cobalt Coupe	T201	T202		
2004 2010	Colorado	T109B		T202	
1987 1996	Corsica	T105B	T105B		
1999 2004	Corvette	T107B			
1987 1987	El Camino	T107BFL			
2005 2009	Equinox	T107B		T202	
2010 2010	Equinox	T203			
1981 1996	G Series Van	T109B			
1987 2005	Impala	T105BFL			
2006 2010	Impala	T201	T201		X
1994 1996	Impala SS	T107B			
1990 2001	Lucerne	T107B			
1990 1996	Malibu	T107B			
1997 2003	Malibu	T101RB	T100B		
1998 2001	Malibu	T201	T201	T202	X
1987 2009	Metro	T105B	T105B		
1987 2009	Monte Carlo	T105BFL			
2000 2005	Monte Carlo	T105BFL	T105BFL		
1999 2000	Pickup	T108B			
1983 1994	S10 Blazer	T108B			
1995 2005	S10 Blazer	T108B			
1982 1992	S10 Pickup	T105B			
1994 2003	S10 Pickup	T108B			
1995 1996	Series 50-65-70	T108B			
1999 2006	Silverado	T107B			
2007 2010	Silverado	T201			
2003 2006	SSR	T107B			
1993 2006	Suburban	T107B			
2000 2001	Suburban	T201			
1995 2006	Tahoe	T107B			
2007 2010	Tahoe	T201			
1998 1998	Tracker	T105B			
1999 2006	Tracker	T101B			
2002 2009	TrailBlazer / EXT	T105B			
CHRYSLER					
2005 2010	300	T101B			
2008 2008	300		T201		X
1999 2004	300	T100B			
1996 2000	Cirrus	T100B	T107B		
1993 2005	Concorde	T107B	T107B		
1985 1986	Executive	T105B			
2000 2000	Grand Voyager	T100B			
1990 1993	Imperial	T105B			
1984 1986	Laser	T107B			
1985 1995	LeBaron	T105B	T105B		
1994 1997	LHS	T107B	T107B		
1999 2001	LHS	T100B	T107B		
1988 1997	New Yorker	T107B			
1985 1988	New Yorker (FWD)	T105B			
2004 2007	Pacifica	T101B			
1995 2000	Sebring	T108B			
2001 2006	Sebring	T100B	T107BFL		
1985 1995	Town & Country	T105B	T108B		
1996 2007	Town & Country	T100B	T202		
2000 2007	Voyager	T100B	T202		

YEAR	MODEL	W/S	B/G	QTR	MTR
DAEWOO					
1995 2002	Lanos	T100B	T107B		
DODGE					
1985 1988	600	T105B			
1985 1989	Aries	T105B			
1996 2000	Avenger	T105B	T108B		
1984 1995	Caravan	T108B			
1996 2007	Caravan	T100B	T202		
2006 2010	Charger	T101B	T101B		
1985 1996	Colt	T107B	T100B		
1984 1984	Colt Vista	T107B			
1989 2000	Dakota Pickup	T108B			
1984 1993	Daytona		T107B		
1998 2000	Durango	T108B			
1988 1993	Dynasty	T105B	T105B		
1987 1995	Grand Caravan	T105B	T108B		
1996 2007	Grand Caravan	T100B	T202		
1993 1997	Intrepid	T107B	T107B		
1998 2005	Intrepid	T100B			
1985 1989	Lancer	T105B	T105B		
2005 2008	Magnum	T100B			
1990 1992	Monaco	T107B	T108B		
1996 2005	Neon	T107B			
2007 2010	Neon	T107B			
1989 1994	Shadow	T107B			
1989 1995	Spirit	T105B	T105B		
1991 1996	Stealth	T107B			
1995 2000	Stratus	T100B	T105B		
1994 2003	Van	T108B			
EXIDE					
1988 1989	Medallion	T107B			
1988 1992	Premier	T107B	T108B		
1989 1996	Summit	T107B	T100B		
1990 1994	Talon	T107B	T107B		
1995 1998	Talon	T108B	T108B		
1993 1997	Vision	T108B	T107B		
FORD					
1990 1997	Aerostar	T107B	T105B		
1994 1997	Aspire	T107B			
1995 2000	Contour	T108B			
2000 2010	Crown Victoria	T107BFL			X
1992 2008	Econoline	T107BFL			
2007 2010	Edge	T101B			X
2001 2010	Escape	T101B			
1989 2002	Escort	T105B	T107B		
1997 2003	Expedition	T100B			
2008 2009	Expedition	T109B			
2010 2010	Expedition	T108B			
1997 2008	F Series/F50	T100B			
2009 2010	F Series/F150	T201			X
2005 2007	Five Hundred	T101B	T201		X
2000 2007	Focus	T101B			
2008 2010	Focus	T100B			
2004 2007	Freestar	T109B			
2005 2009	Fusion	T100B			
2001 2010	Lobo	T201			
1994 2004	Mustang	T107B	T107B		
2005 2010	Mustang	T101B			X
1988 1997	Probe	T105B			
1986 2001	Taurus	T107B	T107BFL		
2000 2007	Taurus	T107B	T201		X
2008 2009	Taurus	T108B			
1994 1997	Thunderbird	T108B			
2010 2010	Transit	T101B			
1995 2003	Windstar	T108B	T107B		
2001 2003	XZ2	T105B			
GEO					
1995 1997	Metro	T107B	T105B		
1989 1997	Prizm	T105B	T105B		
1985 1988	Spectrum	T108B			
1990 1993	Storm	T107B			
1989 1997	Tracker	T105B			
GMC					
1997 2002	C Series Med Duty	T108B			
1987 1987	Caballero	T107BFL			T202
2004 2010	Canyon	T109B			
1993 2001	Envoy	T201			
1981 1986	G Series Van	T109B			
1996 2001	Jimmy	T105B			
1995 2002	Pickup	T108B			
1983 1994	S15 Jimmy	T105B			
1982 1990	S15 Pickup	T105B			
1995 2005	Safari	T108B			
1985 1996	Series 50-65-70	T108B			
1999 2003	Sierra	T108B			
2004 2006	Sierra	T107B			
2007 2010	Sierra	T201			T202
1991 1992	Sonoma S15 Pickup	T105B			
1993 2005	Sonoma S15 Pickup	T108B			
1986					