

Honda and Acura Pillar Molding Clip Instructions

Critical Update:

We want to inform you about the A-Pillar clips OEM# 91570-SZA-305 or GGCK 3282 / GGCK 2925 procedures for the following vehicles:

- 2009-2016 Honda Pilot and Odyssey and the
- Acura ZDX and MDX

The instructions refer to the clip being “heat activated.” We have learned from both the Mfg and our clip manufacturer of our replacement clips that the clip installation does not require heat. The white pad on the clip is a cushion and spacer to space the clip from the metal.

Prepare the painted metal surface with isopropyl alcohol so that it is clean and free of residue. With a marker or tape mark off where the clips will be placed. Mix a two-part epoxy like Z-Poxy (from Equalizer){*note only make enough for each side as this cure very fast*} or 3M Scotch-Weld DP-100 NS 3M Scotch-Weld EPX Applicator system. Apply to the clip surface. Apply and press clip to A-pillar and let cure. Repeat on the rest of the clips.